

# EL-USB-TC-LCD

## K, J & T-Type Thermocouple Data Logger with LCD screen

RE5AL°

- Compatible with K, J and T type thermocouples with miniature thermocouple plug connection
- Stores over 32,000 readings
- LogEasy PC software available as a free download
- Supplied with 1.5m K-type thermocouple with 0 to 200°C (32 to 392°F) measurement range
- High contrast LCD, with four digit temperature display function
- Logging rates between 1 second and 12 hours
- Immediate, delayed and push-to-start logging
- User-programmable alarm thresholds
- Status indication via red and green LEDs



This standalone data logger measures and stores more than 32,000 temperature readings from a J, K or T-type thermocouple at a resolution of 0.5°C (1°F). It comes supplied with a K-type thermocouple capable of measuring from 0 to 200°C (32 to 392°F).

Your application will determine which probe is most suitable based on temperature range, accuracy, form and price. A wide variety of alternative thermocouples are available. Please call us for vendor recommendations.

The user can easily set up the logger and view downloaded data by plugging the data logger into a PC's USB port and using the free LogEasy PC software. Data can then be graphed, printed and exported to other applications for detailed analysis.

The high contrast LCD can show a variety of temperature information. At the touch of a button, the user can cycle between the current, maximum and minimum stored values for temperature.

The data logger is supplied with a lithium metal battery which typically gives 2 years' logging life.

### SPECIFICATIONS

Probe measurement range	0 to 200°C (32 to 392°F) K-type (supplied) -200 to +1350°C (-328 to +2462°F) K-type -200 to +1190°C (-328 to +2174°F) J-type -200 to +390°C (-328 to +734°F) T-type
Internal resolution	0.5°C (1°F)
Accuracy (overall error)	±1°C (±2°F) (data logger only - thermocouple error not included)
Logging rate	User selectable between 1 second & 12 hours
Operating temperature range	-10 to +40°C (+14 to +104°F) (data logger only)
Battery Life	2 years (at 25°C and 1 minute logging rate)
Readings	32,510
Dimensions	135 x 24 x 21mm (5.31 x 0.94 x 0.82")

### ACCESSORIES

BAT 3V6 1/2AA	Replacement battery
EL-P-TC-K	Replacement K-type thermocouple probe
EL-DataPad	Handheld datalogger programmer & collector

### INCLUDED IN THE BOX

BAT 3V6 1/2AA	Battery
EL-P-TC-K	K-type thermocouple probe
EL-LCD WALL BRACKET	Mounting Bracket



### CALIBRATION CERTIFICATES AVAILABLE

Re5al offers Calibration Reports and ISO 17025 certificates on request. We are accredited by the RvA. For more information please look at our website [www.re5al.nl/kalibratie](http://www.re5al.nl/kalibratie)



RE5AL°

Meer en Duin 64B  
2163 HC Lisse

Questions? Call us!

**+31 (0)88 4224460**

Or send an email to:

**INFO@RE5AL.NL**

# EL-USB-TC-LCD

## K, J & T-Type Thermocouple Data Logger with LCD screen


RE5AL°

### EL-WIN-USB

LogEasy's PC control software is available as a free download from [www.re5al.nl/support](http://www.re5al.nl/support). Easy to install and use, the control software is compatible with 32-bit and 64-bit versions of Windows 7, 8 & 10. The software is used to set up the logger, download, graph and annotate data or export in Excel, PDF and jpeg formats.

The software allows the following parameters to be configured:

- Logger name
- Measurement parameter (°C or °F)
- Logging rate (user selectable between 1 second and 12 hours)
- High and low alarms
- Immediate and delayed logging start




Download the latest version of the software free of charge from [www.re5al.nl/support](http://www.re5al.nl/support)

### DISPLAY STATUS INDICATION

The EL-USB-TC-LCD features a high contrast LCD which shows logged temperature values using seven segment numbers, along with annunciators. The LCD can also show information regarding the logging status.

The LCD shows three different recorded readings, which can be cycled through using the built-in push button. The most recent logged temperature, maximum logged temperature and minimum logged temperature can be displayed.

To increase battery life it is possible, via the software, to turn off the display or have it active only after pressing the button.



Display	Logger Status	Explanation
d5	Delayed Start	This is shown when the button is pressed and the logger is set to start at a specific date and time
P5	Push to Start	This will flash when the logger is setup for 'Push to Start' logging
109	Logging	This is shown when the logger is running in 'LCD off' mode, and the button is pressed. The display clears again after a short period
- - -	Stopped	If the logger has not been set to log and the button is pressed, three dashes are displayed for a short period

RE5AL°

Meer en Duin 64B  
2163 HC Lisse

Questions? Call us!

+31 (0)88 4224460

Or send an email to:

[INFO@RE5AL.NL](mailto:INFO@RE5AL.NL)

### LED STATUS INDICATION





















EL-USB-TC-LCD features two LEDs:

- The first LED flashes red to indicate that the EL-USB-TC-LCD is in an alarm condition. It will flash when the logged temperature has exceeded a Low or High alarm level.
- The second LED flashes green to indicate that the EL-USB-TC-LCD is not in an alarm condition.

Using EL-WIN-USB it is possible to set the alarm to remain active even if the reading has returned to normal, in which case the alarm LED will continue to flash red. This 'Hold' feature in the software ensures the user is notified that at some point an alarm level has been exceeded, without needing to download the data.

Using the control software it is possible to set a delayed alarm. In this mode the logger has to see multiple consecutive alarms before being activated.

Hold is enabled by default, and can be turned off via the control software. The red LED will then only flash whilst the logger is in an alarm condition. When the temperature returns to normal, the green LED will flash.

 	<b>Green single flash (every 10 seconds)</b> The data logger is currently logging. No alarm
 	<b>Green single flash (every 20 seconds)</b> The data logger is currently logging, however the battery is running low. No alarm
 	<b>Green single flash (every 30 seconds)</b> The data logger is not currently logging, but is primed to start at a later date and time (delayed start)
 	<b>Green double flash (every 20 seconds)</b> The data logger is full and has stopped logging. No alarm
 	<b>Red single flash (every 10 seconds)</b> The data logger is currently logging. Low alarm
 	<b>Red single flash (every 20 seconds)</b> The data logger is currently logging, however the battery is running low. Low alarm
 	<b>Red double flash (every 10 seconds)</b> The data logger is currently logging High alarm
 	<b>Red double flash (every 20 seconds)</b> The data logger is currently logging, however the battery is running low. High alarm
 	<b>Red &amp; Green single flash alternately (every 20 seconds)</b> The data logger is full and has stopped logging. High or low alarm
 	<b>No LEDs flash</b> The data logger is stopped, the battery is empty or there is no battery

# EL-USB-TC-LCD

## K, J & T-Type Thermocouple Data Logger with LCD screen



### BATTERY INFORMATION

#### Replacement

We recommend that you replace the battery annually, or prior to logging critical data. Only use 3.6V ½AA lithium metal batteries. The data logger does not lose its stored readings when the battery is discharged or replaced; however, the data logging process will stop and will not resume until the battery is replaced and the logger restarted by EL-WIN-USB or an EL-DataPad.

Before replacing the battery, remove the data logger from the PC. Please note that leaving the data logger plugged into the USB port for extended periods will cause some of the battery capacity to be lost.

#### Passivation

If left unused for extended periods of time lithium metal batteries, including those used in the LogEasy range of data loggers, naturally form a non-conductive internal layer preventing them from self-discharge and effectively increasing their shelf life. When first installed in the data logger, this may cause a momentary drop in the battery voltage (the Transient Minimum Voltage) as the internal layer is broken down, resulting in the data logger resetting. Inserting the batteries in the data logger and leaving it connected to a PC for about 30 seconds will remove this layer. After this, remove and re-install the batteries to reset the data logger. Overall battery life will not be affected.

#### WARNING

Handle lithium metal batteries carefully, observe warnings on battery casing. Dispose of in accordance with local regulations.